

INSTALLATION INSTRUCTIONS AND CAUTIONS



Easton Pedals

INSTALLATION INSTRUCTIONS

EASTON pedals are standard 9/16 x 20 BSA threading. The pedals are marked "R" indicating the right pedal and "L" indicating the left pedal. The right pedal screws onto the crank arm in a clockwise direction and the left pedal screws on in a counter clockwise direction. Be sure to clean the crank arm threads and grease the threads on the pedal before mounting.

Pedal breakage can lead to loss of control of the bicycle and result in serious personal injury or death. Pedals must be maintained and inspected closely. In particular; after a major impact or accident, even if there is no visible damage, have a dealer inspect the pedals before using the bicycle. Replace your pedals periodically. Consult with your dealer as to the appropriate frequency of replacement. Destroy any pedals you replace for safety reasons.

2 YEAR LIMITED WARRANTY

These EASTON pedals are warranted to be free of defects in materials and workmanship. This warranty is for the original owner only and proof of purchase is required. This warranty is in lieu of all other warranties. EASTON MAKES NO WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE OR WARRANTIES OF MERCHANTABILITY. Depending on Individual State laws, the above exclusion may not apply to you. This warranty gives you specific rights. You may have other legal rights depending on the State in which you reside.

CAUTION!

All EASTON pedals should be installed by a qualified bicycle mechanic. EASTON WILL ASSUME NO LIABILITY FOR PRODUCT IMPROPERLY INSTALLED BY UNQUALIFIED PERSONS.

